

iSpeed for Comate CC/CT

installation manual



STEALTH INSTALL (UNDERNEATH THE BIKE BATTERY)



WARNING: Make sure your e-bike is turned off !

1. Remove the bike battery with your key
2. Remove the cable cover (Use an allen key in small hole)
3. Remove the battery connector plate (five bolts, pay attention to the different type of bolts)
4. Remove the motor controller, the iSpeed connector is shown on the image



5. Disconnect the indicated connector and install the iSpeed module
6. Package everything neatly together
7. Push the cables and motor controller back into the frame
8. Re-install the battery connector plate (insert the lock key for easier installation), re-install the cable cover and place the battery

