

# iSpeed for Veloretti bikes

## installation manual



### STEALTH INSTALL (INSIDE THE BAFANG MOTOR)



**WARNING: Make sure your e-bike is turned off !**

1. Loosen the motor cover by removing the three bolts, carefully remove the cover and place the IoT module to the side
2. Identify the purple connector inside the motor (It may be fitted with a protective cap)
3. Connect the iSpeed module to the purple connector
4. Tuck the iSpeed module away in the opening on the top right, put back the IoT module and mount the motor cover with the 3 screws

